

why use greenspeed® microfiber cloths




- Highly absorbent
- quickly
- Dries No streaks
- Shrink-free and keeps it shape due to reinforced sewn edges
- Time savings through effective and fast cleaning
- Savings on detergent use
- Certified under the Nordic Swan Ecolabel for quality, longevity and environmentally friendly.

how to use

- Before using for the first time, wash the cloth once in the washing machine



- Use damp, but not saturated for cleaning
- Use dry for dusting



- Fold the cloth as shown on the image
- Use all 16 surfaces one by one and change regularly



MICROFIBER WASHING & DRYING INSTRUCTIONS

Cloths, dusters and mops made of microfiber can last hundreds of washings if you stay away from the 2 big no-no's for microfiber:

- No Heat!
- No Fabric Softeners!

INSTRUCTIONS FOR WASHING AT HOME

Washing

- Wash in warm water with a mild detergent
- No fabric softeners - they clog the open spaces in the microfiber, making the fabric useless
- Be careful what you wash with your microfiber. Avoid anything made with cotton because lint will grab on to the microfiber
- Ideally wash microfiber with only microfiber but if you must mix loads, wash with other non-linting synthetics
- If you hand wash, wash in warm water with a mild detergent and use a soft bristled brush if necessary
- Rinse thoroughly.

Drying

- To ensure the longest lasting microfiber, air dry is best
- Microfiber dries relatively quickly. If you use a dryer, set it on low heat or no heat
- Dry with other microfiber products only so that it doesn't pick up extra lint

FOR MAXIMUM PERFORMANCE AND LOGGEVITY, FOLLOW THESE GUIDELINES FOR COMMERCIAL LAUNDERING

Washing

- Wash (Max Temp 190F)
- Detergent
- No Alkaline
- Dose determined by product specification for poundage
- No Bleach
- No Fabric Softener

Drying

- Tumble Dry (Max Temp 100F)



Suitable for washing machine



Do not iron



Do not use fabric softener



Do not use bleach



Suitable for tumble dryer



Can be washed at 90°

